Part	Activity	Before use	After use	Every month	Yearly	Every 3 years	Every 10 years
Complete device	Cleaning and disinfection		Х				
	Visual check	Х	Х	Х			
	Leakage control and alarm signal	Х		Х			
Demand valve	Testing with bench and leakage		Xª		Х		
	Membrane replacement		Xa			Х	
Pressure reducer	Testing with bench and leakage				Х		
	Replacing the high-pressure connector O-ring				Х		
	Testing the thread of the valve connection (with 5/8" gas gauge)						X ^d
	Overhaul (note b)						Xq
Cylinder	Recharge to the correct operating pressure	Х	х				
	Charge control (only for stock cylinders)			Х			
	Checking the test expiry date				Х		
	Recertification	According to national regulations in the country of use					
Cylinder valve	Re-testing (note c)	At the time of cylinder recertification					
Note a) After use in corrosive environments or under extreme environmental conditions Note b) For self-contained breathing apparatuses that are frequently used, SPASCIANI recommends a full overhaul after approximately 600 hours, which corresponds, for example, to 1200 uses of 30 minutes each, including training activities.							
Note c) Every time you disassemble the valve of the cylinder, you must replace it with a new one. Refer to the instructions							

manual of the cylinder and valve for the proper torque values.

Note d) Operations to be performed only by SPASCIANI